Thermo Scientific Orion RDO® Optical DO Sensor Important Notes




Read these notes before assembling or operating the RDO sensor

Do not touch the bottom of the RDO cap, optical window or spring contacts on the RDO sensor.

The silicone grease that is supplied with the RDO cap should only be used to lubricate the two O-rings on the RDO sensor. Do not fill the RDO cap with the silicone grease, as this will impair the function of the RDO sensor and damage the optical window and RDO cap.

Do not immerse the RDO sensor in a solution unless the RDO cap is properly installed on the sensor.

The RDO sensor has an internal clock that counts down the 365 day lifespan of a new RDO cap. The countdown begins when the RDO cap is installed on the RDO sensor, the sensor is connected to the meter and the first measurement is taken. The 365 day countdown cannot be reset or changed once the first measurement is taken.



©2008 Thermo Fisher Scientific Inc. All rights reserved. RDO is a registered trademark of In-Situ Inc., Fort Collins, CO USA. All other trademarks are the property of Thermo Fisher Scientific Inc. and its subsidiaries.

Environmental Instruments Water Analysis Instruments

North America 166 Cummings Center Beverly, MA 01915 USA Toll Free: 1-800-225-1480 Tel: 1-978-232-6000 Dom. Fax: 1-978-232-6015 Int'l Fax: 978-232-6031 www.thermo.com/water Europe P.O. Box 254, 3860 AG Nijkerk Wallerstraat 125K, 3862 BN Nijkerk, Netherlands Tel: (31) 033-2463887 Fax: (31) 033-2460832 Registered Quality System ISO 9001:2000

Asia Pacific Blk 55, Ayer Rajah Crescent #04-16/24, Singapore 139949 Tel: 65-6778-6876 Fax: 65-6773-0836

257822-001 Rev. A 10-08

